

BODY SECTION

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

**HVAC SYSTEM
(HEATER, VENTILATOR AND A/C)** AC

**HVAC SYSTEM (AUTO A/C)
(DIAGNOSTICS)** AC

AIRBAG SYSTEM AB

AIRBAG SYSTEM (DIAGNOSTICS) AB

SEAT BELT SYSTEM SB

LIGHTING SYSTEM LI

WIPER AND WASHER SYSTEMS WW

ENTERTAINMENT ET

COMMUNICATION SYSTEM COM

GLASS/WINDOWS/MIRRORS GW

BODY STRUCTURE BS

INSTRUMENTATION/DRIVER INFO IDI

SEATS SE

SECURITY AND LOCKS SL

IMMOBILIZER (DIAGNOSTICS) IM

**SUNROOF/T-TOP/CONVERTIBLE TOP
(SUNROOF)** SR

EXTERIOR/INTERIOR TRIM EI

INSTRUMENTATION/DRIVER INFO



	Page
1. General Description	2
2. Combination Meter System.....	4
3. Combination Meter Assembly	19
4. Speedometer.....	21
5. Tachometer	22
6. Fuel Gauge	23
7. Water Temperature Gauge	24
8. Ambient Sensor.....	25

GENERAL DESCRIPTION

INSTRUMENTATION/DRIVER INFO

1. General Description

A: SPECIFICATIONS

Combination meter	Speedometer	Electric pulse type
	Temperature gauge	Thermistor cross coil type
	Fuel gauge	Resistance cross coil type
	Tachometer	Electric impulse type
	Turn signal indicator light	14 V — 1.4 W
	Charge indicator light	LED
	Oil pressure indicator light	LED
	ABS warning light	LED
	CHECK ENGINE warning light (Malfunction indicator light)	LED
	HI-beam indicator light	14 V — 1.4 W
	Door open warning light	LED
	Seat belt warning light	LED
	Brake fluid and parking brake warning light	LED
	FWD indicator light	LED
	AIRBAG warning light	LED
	Meter illumination light	14 V — 3 W, 14 V — 2 W
	AT OIL TEMP. warning light	LED
	LO indicator light	LED
	HOLD indicator light	LED
	Immobilizer indicator light	LED
	POWER indicator light	14 V — 2 W
	Low fuel warning light	LED
	AT select lever position indicator light	14 V — 100 mA
	LCD back light	14 V — 1.4 W

GENERAL DESCRIPTION

INSTRUMENTATION/DRIVER INFO

B: CAUTION

- Be careful not to damage meters and instrument panel.
- Be careful not to damage meter glasses.
- Make sure that electrical connector is connected securely.
- After installation, make sure that each meter operates normally.
- Use gloves to avoid damage and getting fingerprints on the glass surface and meter surfaces.
- Do not apply excessive force to circuit plate.
- Do not drop or otherwise apply impact.

C: PREPARATION TOOL

1. GENERAL TOOLS

TOOL NAME	REMARKS
Circuit Tester	Used for measuring resistance and voltage.

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO


2. Combination Meter System

A: SCHEMATIC

1. COMBINATION METER

METER-01

METER-01




COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO


METER-02

METER-02



COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO



IDI-6


GG64-20C

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

METER-04

METER-04




AT : AT MODEL
 MT : MT MODEL
 AC : WITH AUTO A/C MODEL

GG64-20D

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO


2. OUTSIDE TEMPERATURE INDICATOR LHD MODEL



F78




A: i10 (GREEN)



A: B282 (GRAY)




B: B283 (GRAY)




i2

F45



B36 (BLACK)



B: i11 (GREEN)



GL96-20










COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

3. OUTSIDE TEMPERATURE INDICATOR RHD MODEL

O/T(R)-01

O/T(R)-01



COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

B: INSPECTION

CAUTION:

When measuring voltage and resistance of the ECM, TCM, or each sensor, use a tapered pin with a diameter of less than 0.64 mm (0.025 in) in order to avoid poor contact. Do not insert the pin more than 2 mm (0.08 in).

1. SYMPTOM CHART

Symptom	Repair order	Reference
Combination meter assembly does not operate.	(1) Power supply (2) Ground circuit	<Ref. to IDI-11, CHECK POWER SUPPLY AND GROUND CIRCUIT, INSPECTION, Combination Meter System.>
Speedometer does not operate.	(1) (MT) Vehicle speed sensor (AT) Transmission control module (2) Harness (3) Speedometer	MT: <Ref. to IDI-12, CHECK VEHICLE SPEED SENSOR, INSPECTION, Combination Meter System.>
		AT: <Re. to IDI-<Ref. to IDI-13, CHECK TRANSMISSION CONTROL MODULE, INSPECTION, Combination Meter System.>
Tachometer does not operate.	(1) Engine control module (2) Harness (3) Tachometer	<Ref. to IDI-14, CHECK ENGINE CONTROL MODULE, INSPECTION, Combination Meter System.>
Fuel gauge does not operate.	(1) Fuel level sensor (2) Harness (3) Fuel gauge	<Ref. to IDI-15, CHECK FUEL LEVEL SENSOR, INSPECTION, Combination Meter System.>
Water temperature gauge does not operate.	(1) Engine coolant temperature sensor (2) Harness (3) Water temperature gauge	<Ref. to IDI-16, CHECK ENGINE COOLANT TEMPERATURE SENSOR, INSPECTION, Combination Meter System.>
Outside temperature indicator does not operate.	(1) Ambient sensor (2) Harness (3) Combination meter (4) Auto A/C control module	<Ref. to IDI-17, CHECK OUTSIDE TEMPERATURE INDICATOR, INSPECTION, Combination Meter System.>

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

2. CHECK POWER SUPPLY AND GROUND CIRCUIT

Step	Check	Yes	No
<p>1</p> <p>CHECK POWER SUPPLY FOR COMBINATION METER. 5)Remove combination meter. <Ref. to IDI-19, REMOVAL, Combination Meter Assembly.> 6)Disconnect combination meter harness connector. 7)Turn ignition switch to ON. 8)Measure voltage between combination meter connector (i10) and chassis ground. Connector & terminal (i10) No. 7 (+) — Chassis ground (-):</p>	Is the voltage more than 10 V?	Go to step 2.	Check harness for open or short between ignition switch and combination meter.
<p>2</p> <p>CHECK POWER SUPPLY FOR COMBINATION METER. Measure voltage between combination meter connector (i10) and chassis ground. Connector & terminal (i10) No. 10 (+) — Chassis ground (-):</p>	Is the voltage more than 10 V?	Go to step 3.	Check harness for open or short between fuse and combination meter.
<p>3</p> <p>CHECK GROUND CIRCUIT OF COMBINATION METER. 1)Turn ignition switch to OFF. 2)Measure resistance of harness between combination meter connector (i10) and chassis ground. Connector & terminal (i10) No. 6 (+) — Chassis ground (-):</p>	Is the resistance less than 10 Ω ?	Replace combination meter printed circuit.	Repair wiring harness.

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

3. CHECK VEHICLE SPEED SENSOR

Step	Check	Yes	No
<p>1 CHECK VEHICLE SPEED SENSOR. 1)Set the vehicle on a free roller, or lift-up the vehicle and support it with safety stands. 2)Remove the combination meter with harness connector.</p> <p>Warning: Be careful not to get caught in the running wheels.</p> <p>3)Drive the vehicle at a speed greater than 20 km/h (12 MPH). 4)Measure voltage between combination meter connector (i10) and chassis ground.</p> <p>Connector & terminal (i10) No. 2 (+) — Chassis ground (-):</p>	<p>Is the voltage less than 1V ←→ more than 4 V?</p>	<p>Check speedometer. <Ref. to IDI-21, REMOVAL, Speedometer.></p>	<p>Go to step 2.</p>
<p>2 CHECK VEHICLE SPEED SENSOR POWER SUPPLY. 1)Turn ignition switch to OFF. 2)Disconnect vehicle speed sensor harness connector. 3)Turn ignition switch to ON. 4)Measure voltage between vehicle speed sensor connector (B17) and engine ground.</p> <p>Connector & terminal (B17) No. 3 (+) — Engine ground (-):</p>	<p>Is the voltage more than 10 V?</p>	<p>Go to step 3.</p>	<p>Check harness for open or short between ignition switch and vehicle speed sensor.</p>
<p>3 CHECK HARNESS BETWEEN VEHICLE SPEED SENSOR AND ENGINE GROUND. 1)Turn ignition switch to OFF. 2)Measure resistance between vehicle speed sensor connector (B17) and engine ground.</p> <p>Connector & terminal (B17) No. 2 (+) — Engine ground (-):</p>	<p>Is the resistance less than 10 Ω?</p>	<p>Go to step 4.</p>	<p>Repair wiring harness.</p>
<p>4 CHECK HARNESS BETWEEN VEHICLE SPEED SENSOR AND COMBINATION METER. 1)Disconnect connector from combination meter. 2)Measure resistance between vehicle speed sensor harness connector and combination meter harness connector.</p> <p>Connector & terminal (B17) No. 1 — (i10) No. 2:</p>	<p>Is the resistance less than 10 Ω?</p>	<p>Replace vehicle speed sensor.</p>	<p>Repair wiring harness.</p>

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

4. CHECK TRANSMISSION CONTROL MODULE

Step	Check	Yes	No
<p>1</p> <p>CHECK TRANSMISSION CONTROL MODULE SIGNAL.</p> <p>1) Set the vehicle on a free roller, or lift-up the vehicle and support it with safety stands.</p> <p>Warning: Be careful not to get caught in the running wheels.</p> <p>2) Drive the vehicle faster than 10 km/h (6 MPH).</p> <p>3) Measure voltage between transmission control module connector (B56) and chassis ground.</p> <p>Connector & terminal (B56) No. 17 (+) — Chassis ground (-):</p>	<p>Is the voltage less than 1 V ←→ more than 4 V?</p>	<p>Go to step 2.</p>	<p>Check transmission control module. <Ref. to AT-2, Basic Diagnostic Procedure.></p>
<p>2</p> <p>CHECK HARNESS BETWEEN TRANSMISSION CONTROL MODULE AND COMBINATION METER.</p> <p>1) Turn ignition switch to OFF.</p> <p>2) Disconnect connector from transmission control module and combination meter.</p> <p>3) Measure resistance between transmission control module harness connector (B56) and combination meter harness connector (i10).</p> <p>Connector & terminal (B56) No. 17 — (i10) No. 2:</p>	<p>Is the resistance less than 10 Ω?</p>	<p>Check speed meter. <Ref. to IDI-21, REMOVAL, Speedometer.></p>	<p>Repair wiring harness.</p>

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

5. CHECK ENGINE CONTROL MODULE

Step	Check	Yes	No
<p>1</p> <p>CHECK ENGINE CONTROL MODULE SIGNAL.</p> <p>1)Start the engine. 2)Measure voltage between engine control module connector (B136: turbo engine model) or (B134: non-turbo engine model) and engine ground.</p> <p>Connector & terminal Turbo engine model: (B136) No. 9 (+) — Engine ground (-): Non-turbo engine model: (B134) No. 30 (+) — Engine ground (-):</p>	<p>Is the voltage 0 ↔ 13 V or more?</p>	<p>Go to step 2.</p>	<p>Check engine control module. <Ref. to EN(SOHC)-2, Basic Diagnostic Procedure.> or <Ref. to EN(SOHCw/oOBD)-2, Basic Diagnostic Procedure.> or <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.></p>
<p>2</p> <p>CHECK HARNESS BETWEEN COMBINATION METER AND ENGINE CONTROL MODULE.</p> <p>1)Turn ignition switch to OFF. 2)Disconnect connector from engine control module and combination meter. 3)Measure resistance between engine control module harness connector (B136: turbo engine model) or (B134: non-turbo engine model) and combination meter harness connector (i10).</p> <p>Connector & terminal Turbo engine model: (B136) No. 9 — (i10) No. 5: Non-turbo engine model: (B134) No. 30 — (i10) No. 5:</p>	<p>Is the resistance less than 10 Ω?</p>	<p>Check tachometer. <Ref. to IDI-22, REMOVAL, Tachometer.></p>	<p>Repair wiring harness.</p>

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

6. CHECK FUEL LEVEL SENSOR

Step	Check	Yes	No
1	CHECK ENGINE TYPE.	Go to step 3 .	Go to step 2 .
2	CHECK FUEL LEVEL SENSOR. 1)Check fuel level sensor. <Ref. to EN(SOHC)-186, DTC P0462 — FUEL LEVEL SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> or <Ref. to EN(DOHC TURBO)-190, DTC P0462 — FUEL LEVEL SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Check fuel gauge. <Ref. to IDI-23, REMOVAL, Fuel Gauge.>	Replace the fuel level sensor.
3	CHECK FUEL LEVEL SENSOR. 1)Remove fuel level sensor. <Ref. to FU(SOHCw/oOBD)-56, REMOVAL, Fuel Level Sensor.> 2)Measure resistance between fuel level sensor terminals when setting the float to FULL and EMPTY position. Terminals No. 3 — No. 5:	Go to step 4 .	Replace the fuel level sensor.
4	CHECK HARNESS BETWEEN FUEL LEVEL SENSOR AND COMBINATION METER. 1)Disconnect connector from combination meter. 2)Measure resistance between fuel level sensor harness connector terminal and combination meter harness connector terminal. Connector & terminal (R58) No. 3 — (i12) No. 2:	Go to step 5 .	Repair wiring harness.
5	CHECK FUEL LEVEL SENSOR GROUND CIRCUIT. Measure resistance between fuel level sensor harness connector terminal and chassis ground. Connector & terminal (R58) No. 5 — Chassis ground:	Fuel level sensor is OK.	Repair wiring harness.

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

7. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Step	Check	Yes	No
<p>1</p> <p>CHECK ENGINE COOLANT TEMPERATURE SENSOR. Check engine coolant temperature sensor. <Ref. to EN(SOHC)-122, DTC P0117 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> or <Ref. to EN(SOHCw/oOBD)-76, DTC 21 ENGINE COOLANT TEMPERATURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> or <Ref. to EN(DOHC TURBO)-114, DTC P0117 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).></p>	<p>Is engine coolant temperature sensor OK?</p>	<p>Go to step 2.</p>	<p>Replace engine coolant temperature sensor.</p>
<p>2</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND COMBINATION METER. 1) Turn ignition switch to OFF. 2) Disconnect connector from engine coolant temperature sensor and combination meter. 3) Measure resistance between engine coolant temperature sensor harness connector (E8) and combination meter harness connector (i12). Connector & terminal (E8) No. 3 — (i12) No. 9:</p>	<p>Is the resistance less than 10 Ω?</p>	<p>Check water temperature gauge. <Ref. to IDI-24, REMOVAL, Water Temperature Gauge.></p>	<p>Repair wiring harness.</p>

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

8. CHECK OUTSIDE TEMPERATURE INDICATOR

Step	Check	Yes	No	
1	CHECK AIR CONDITIONER TYPE.	Is the vehicle equipped with auto A/C?	Go to step 6.	Go to step 2.
2	CHECK POWER SUPPLY FOR AMBIENT SENSOR. 1) Turn ignition switch OFF. 2) Disconnect connector from combination meter. 3) Turn ignition switch ON. 4) Measure voltage between combination meter terminal and chassis ground. Connector & terminal (i11) No. 11 (+) — Chassis ground (-):	Is the voltage more than 4V?	Go to step 3.	Replace combination meter printed circuit.
3	CHECK HARNESS BETWEEN AMBIENT SENSOR AND COMBINATION METER. 1) Turn ignition switch OFF. 2) Disconnect connector from ambient sensor. 3) Measure resistance between ambient sensor harness connector terminal and combination meter harness connector terminal. Connector & terminal LHD model: (F78) No. 1 — (i11) No. 11: (F78) No. 2 — (i11) No. 8: RHD model: (F78) No. 2 — (i11) No. 11: (F78) No. 1 — (i11) No. 8:	Is the resistance less than 10 Ω?	Go to step 4.	Repair wiring harness.
4	CHECK AMBIENT SENSOR. 1) Remove ambient sensor. 2) Check ambient sensor. <Ref. to IDI-25, INSPECTION, Ambient Sensor.>	Is the ambient sensor OK?	Go to step 5.	Replace the ambient sensor.
5	CHECK OUTSIDE TEMPERATURE INDICATOR. 1) Connect combination meter harness connector. 2) Connect a resistor (2.2 kΩ) between terminals of ambient sensor harness connector. 3) Turn ignition switch ON and check the outside temperature indicator display.	Is the outside temperature indicator indicating 25°C (77°F)?	Repair poor contact of ambient sensor harness connector.	Replace combination meter printed circuit.
6	CHECK POWER SUPPLY FOR COMBINATION METER. 1) Turn ignition switch OFF. 2) Disconnect connector from auto A/C control module. 3) Turn ignition switch ON. 4) Measure voltage between auto A/C control module terminal and chassis ground. Connector & terminal (B282) No. 11 (+) — chassis ground (-):	Is the voltage more than 4V?	Go to step 7.	Replace auto A/C control module.

COMBINATION METER SYSTEM


INSTRUMENTATION/DRIVER INFO

Step	Check	Yes	No
7 CHECK HARNESS BETWEEN AUTO A/C CONTROL MODULE AND COMBINATION METER. 1) Turn ignition switch OFF. 2) Disconnect connector from combination meter. 3) Measure resistance between auto A/C control module harness connector terminal and combination meter harness connector terminal. Connector & terminal (B282) No. 11 — (i11) No. 12:	Is the resistance less than 10 Ω ?	Go to step 8.	Repair wiring harness.
8 CHECK POWER SUPPLY FOR AMBIENT SENSOR. 1) Turn ignition switch ON. 2) Measure voltage between auto A/C control module terminal and chassis ground. Connector & terminal (B283) No. 9 (+) — chassis ground (-):	Is the voltage more than 4V?	Go to step 9.	Replace auto A/C control module.
9 CHECK HARNESS BETWEEN AMBIENT SENSOR AND COMBINATION METER. 1) Turn ignition switch OFF. 2) Disconnect connector from ambient sensor. 3) Measure resistance between ambient sensor harness connector terminal, combination meter harness connector terminal and auto A/C control module harness connector terminal. Connector & terminal LHD model: (F78) No. 1 — (i11) No. 11: (F78) No. 1 — (B283) No. 9: (F78) No. 2 — (i11) No. 8: RHD model: (F78) No. 2 — (i11) No. 11: (F78) No. 2 — (B283) No. 9: (F78) No. 1 — (i11) No. 8:	Is the resistance less than 10 Ω ?	Go to step 10.	Repair wiring harness.
10 CHECK AMBIENT SENSOR. 1) Remove ambient sensor. 2) Check ambient sensor. <Ref. to IDI-25, INSPECTION, Ambient Sensor.>	Is the ambient sensor OK?	Go to step 11.	Replace the ambient sensor.
11 CHECK OUTSIDE TEMPERATURE INDICATOR. 1) Connect combination meter and auto A/C control module harness connector. 2) Connect a resistor (2.2 k Ω) between terminals of ambient sensor harness connector. 3) Turn ignition switch ON and check the outside temperature indicator display.	Is the outside temperature indicator indicating 25°C (77°F)?	Repair poor contact of ambient sensor harness connector.	Replace combination meter printed circuit.


3. Combination Meter Assembly

A: REMOVAL

- 1) Disconnect ground cable from battery.
- 2) Set tilt steering at the lowest position.
- 3) Remove screws and detach meter visor.



- 4) Remove screws of combination meter and pull out the meter toward you.



- 5) Disconnect connector in the upper area of combination meter to remove meter.

CAUTION:

- Be careful not to damage meter or instrument panel.
- Pay particular attention to avoid damaging the meter glass.

B: INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Make sure that electrical connector is connected securely.
- Make sure that each meter operates normally.

COMBINATION METER ASSEMBLY


INSTRUMENTATION/DRIVER INFO

C: DISASSEMBLY

CAUTION:

Use gloves to avoid damage and getting fingerprints on the glass surface and meter surfaces.


- 1) Disengage claw (F) to remove case (B) from back cover (A).
- 2) Disengage claw (G) to remove meter glass (E), reflector (D), and window plate (C) from inner case.



BO0014


3) Pull up claw (A) in portion (B) of combination meter printed circuit (C) with combination pliers. Push out speedometer and tachometer assembly (D) and fuel gauge and water temperature gauge assembly (E) using hole (F).

4) Pull up claw in the center of combination meter printed circuit (C), and remove circuit plate from case (G).



BO0015

1. BULB REPLACEMENT



BO0016

- (1) Tachometer
- (2) Speedometer and tachometer
- (3) Turn RH
- (4) HI-beam
- (5) Speedometer
- (6) POWER
- (7) Turn LH
- (8) Fuel gauge
- (9) Temperature gauge
- (10) LCD (Outside temperature indicator)
- (11) LCD (Odometer and tripmeter)

D: ASSEMBLY

Assemble in the reverse order of disassembly.

4. Speedometer

A: REMOVAL


Disassemble combination meter, and then remove speedometer and tachometer assembly. <Ref. to IDI-20, DISASSEMBLY, Combination Meter Assembly.>

B: INSTALLATION

Install in the reverse order of removal.

C: INSPECTION

Measure resistance between speedometer terminals.



Tester connection	Resistance
Terminals SIN+ —SIN—	200±8 Ω
Terminals COS+ —COS—	200±8 Ω

If NG, replace speedometer and tachometer assembly.

If OK, replace combination meter printed circuit.

5. Tachometer

A: REMOVAL


Disassemble combination meter, and then remove speedometer and tachometer assembly. <Ref. to IDI-20, DISASSEMBLY, Combination Meter Assembly.>

B: INSTALLATION

Install in the reverse order of removal.

C: INSPECTION

Measure resistance between tachometer terminals.



Tester connection	Resistance
Terminals SIN+ —SIN—	200±8 Ω
Terminals COS+ —COS—	200±8 Ω

If NG, replace speedometer and tachometer assembly.

If OK, replace combination meter printed circuit.

6. Fuel Gauge

A: REMOVAL


Disassemble combination meter, and then remove water temperature gauge and fuel gauge assembly. <Ref. to IDI-20, DISASSEMBLY, Combination Meter Assembly.>

B: INSTALLATION

Install in the reverse order of removal.

C: INSPECTION

Measure resistance between fuel gauge terminals.



Tester connection	Resistance
Terminals IGN — GND	170±10 Ω
Terminals IGN — UNIT	35±10 Ω
Terminals UNIT — GND	136±10 Ω

If NG, replace water temperature gauge and fuel gauge assembly.

If OK, replace combination meter printed circuit.

WATER TEMPERATURE GAUGE

INSTRUMENTATION/DRIVER INFO

7. Water Temperature Gauge

A: REMOVAL


Disassemble combination meter, and then remove tachometer and water temperature gauge and fuel gauge assembly. <Ref. to IDI-20, DISASSEMBLY, Combination Meter Assembly.>

B: INSTALLATION

Install in the reverse order of removal.

C: INSPECTION

Measure resistance between fuel gauge terminals.



Tester connection	Resistance
Terminals IGN — GND	$208 \pm 10 \Omega$
Terminals IGN — UNIT	$56 \pm 10 \Omega$
Terminals UNIT — GND	$264 \pm 10 \Omega$


If NG, replace water temperature gauge and fuel gauge assembly.

If OK, replace combination meter printed circuit.

8. Ambient Sensor

A: REMOVAL

- 1) Disconnect ground cable from battery.
- 2) Disconnect ambient sensor connector.
- 3) Remove ambient sensor (A) from radiator lower panel.




B: INSTALLATION

Install in the reverse order of removal.

C: INSPECTION

Measure resistance between ambient sensor terminals.



Tester connection	Resistance
1 — 2	2.2 kΩ/25°C (77°F)

If NG, replace the ambient sensor.

